



41041 Black Bayou Rd, Gonzales, Louisiana, USA 70737
Phone (225) 644-5255 FAX (225) 644-3975

www.geniefilters.com sales@geniefilters.com

INSTALLATION INSTRUCTIONS

**SAMPLE MASTER FILTER MODEL 410 Part# 410-000-SS
MEGA GLYSORB CARTRIDGE Part # 103-505**

Revision 6.06

INSTALLATION INSTRUCTIONS

SAMPLE MASTER FILTER MODEL 410

The Sample Master Filter is designed to accommodate a variety of A+ CORP filter cartridges. The filter has ¼" female NPT connections at both ends, and it is comprised of two parts (one male and one female). It may be disassembled by grasping the flat portions of each half by hand and turning counterclockwise. Filter cartridges may be installed as follows. Insert one end of the cartridge into the male half of the filter. Slide the O-ring over the exposed end of the cartridge until it bottoms against the male half. Hold the male half vertical. Slide the female half (non-NPT end down) over the cartridge and hand tighten by turning the two halves clockwise. The filter may be installed in-line using ¼" NPT male adapters. Wrench flats are provided to ease initial installation of ¼" NPT male adapters.

CAUTION: Maximum Allowable Working Pressure (MAWP) = 4,000 PSI with greater than 4:1 safety factor.

Replacement O-rings are available.

SAMPLE MASTER FILTER 410 (CUTAWAY VIEW)

